

【X-431 Knowledge article】 Audi A3, A3quattro battery power failure, the car window, skylight, remote control and steering Angle sensor learning method

Operation Method

1 Automatic engine adaptation method

- a) When the battery power is not connected, connect the positive electrode and the grounding line;
- b) Switch on the ignition;
- c) Waiting for 5 seconds;
- d) Start engine for 3 minutes to adjust.

2 Electronic window and window learning method

- a) Switch on the ignition;
- b) Lift and press the window switch and close the window completely;
- c) Release the switch;;
- d) Lift and hold down the window switch for 1 second;
- e) Repeat the process to operate the other Windows;

3 The learning method of remote control alarm and control door lock

- a) Open the driver side door manually with the key;

- b) Press and hold on remote control alarm “Unlock” key once.
- c) Switch on the ignition;
- d) Switch off the ignition;
- e) Pulled out the key from the ignition switch;
- f) Use the remote alarm LOCK or UNLOCK once;
- g) System return to normal.

4 Steering Angle sensor ESP warning light

The ESP warning lights will extinguish if you travel in a straight line between 9 and 12 miles per hour.