

# 2006 Buick GL8FirstLand oil reset operation

## Car Model

ShangHai GM Buick, 2006, VIN=LSGUD82C36E029343, Pic1;




Pic1

## Notice

1. Switch on the ignition;
2. Keep battery voltage keep more than 12V;
3. Excuting when the wifi state in good ,otherwise it will cause diagnose abnormally.


## Operation Instruction

1. Select Chinese GM V48.90 above;
2. Select manually ,Note: do not choose the online programming. See as pic 2;




pic2

3. Select "Buick"; see as pic 3;



pic3

4. Select Year of Model 2006, pic4;




pic4

5. Select “Engine control module”, pic5;




图5

6. Select the engine type “(C)3.0LV6 LZC”pic 6;



Pic6

7. Select “Special function”, see pic7;



Pic7

8. Select oil reset, Display engine oil life currently value 51%, see as pic8;



pic8

9. Click input, after clicking 100 ,then click reset.



pic9

10. When the engine oil life transfer from 51% to 100%.It indicates reset successful. see as10.



11. Turn off the key, exit the software. Operation end.